



DFMZ
DESIGN FILTRATION MICROZONE



A LEADER IN BUILDING CLEANER ENVIRONMENTS

1.5 Cleanroom Wall System

The DFMZ 1.5 Cleanroom Wall System is our most popular wall system. It's key to a rigid and strong enclosure at a very attractive price. Wall modules are constructed with a heavy-duty, anodized, extruded aluminum frame containing a choice of insert panels. The DFMZ 1.5 System is used in a wide variety of applications. Originally developed for Pharmacy Compounding, it is also used for pharmaceutical manufacturing, electronic production and university research labs.



Key Features

- Heavy-duty, anodized, extruded aluminum frame (1-5/8" or 2" thick)
- Solid white polypropylene and clear acrylic inserts
- Ceiling height of 8'; however, virtually any height up to 16' can be provided
- Sliding or swing doors constructed with extruded aluminum frames and clear acrylic inserts
- Anodized, aluminum service chases with snap covers allow for easy installation and future modification of services
- Typically installed along with DFMZ 2.0 Ceiling Grid

Standard Features

Optional Features

- DFMZ - Double Track - Flush face on both sides
- White powder coat finish on aluminum extrusions
- Automated doors

06-05-2019

Call Toll Free: (888) 636-8609

<http://www.dfmzgroup.com>