

TruScript™

EASY, SAFE, AND ACCURATE
SEMI-AUTOMATED VIAL FILLING



Secure, accurate and user-friendly, the TruScript™ is the right choice for efficient and scalable vial-filling. With flexible arrangements, it delivers accurate dispensing solutions for any size pharmacy operation.

Why Choose TruScript™?

- Scalable design to fit any size pharmacy
- Auto-locking canisters to control access and improve security
- No rear access required for operation and easy pharmacy integration
- Ability to link multiple devices together to expand your formulary capacity
- Intelligently routes scripts to dispense in sequence based on priority status
- No cross contamination, no compressed air, no complicated moving parts

Improve Your Prescription Filling Process with TruScript Flexibility

- Under 5 square feet, with 54 locking 900 cc cassettes, the most drug cells per square foot in the industry
- Link units for ultimate flexibility in a variety of arrangements
- Large "holding chutes" for 90-day fills
- Accommodates any size and type of vial

Ease of Use

- Pill chutes detach for easy cleaning
- High Capacity Canisters minimize refills and maximize production
- Barcode scanner for verifying each prescription and canister refill

Safety

- The most accurate counting technology ensures accurate dispensing
- Locking chutes require Rx scan to ensure right prescription for right chute
- Direct-fill chutes eliminates cross-contamination
- Secure and repeatable fulfillment



TruScript™

EASY, SAFE, AND ACCURATE
SEMI-AUTOMATED VIAL FILLING



1. TruScript interfaces with PIS to route prescriptions.



2. Medication is dispensed from a locked canister into a secured chute.



3. Pharmacy staff scans the vial label and the chute illuminates, ensuring the correct fulfillment.



4. Medication is dispensed.



5. Same drug scripts intelligently queue so one counts and stages after the other.



6. Software-enabled script prioritization for waiting customers.

Get Complete Workflow Visibility with Enlite™ Enterprise Software

We offer a complete suite of pharmacy automation solutions managed through one cloud-based ecosystem, Enlite. This unique ecosystem turns any number of unique systems into a single solution and delivers a higher level of efficiency, analytics, and reporting not available before in the industry.

Traditional systems operate independently and make tasks redundant and time-consuming. The groundbreaking Enlite Management System addresses inefficiencies and communication barriers in the pharmacy industry's current automation process.

TruScript™ Specifications

Spec	Value
Dimensions	1520 (w) x 320 (d) X 2040 (h) mm
Weight	260Kg (Machine only)
Power Supply	AC110V 50Hz / Transformer AC240V 50Hz
Number of canisters	54pcs
Capacity of canisters	900cc

To learn more or to request a demo, contact your Healthmark sales representative.

